


## I Instructions For Use

Security Notification: The bill counter should be used on a stable platform, away from vibration, high temperature, and strong light. Keep each rubber wheel clean and free of dirt, liquid, grease, etc., otherwise it will cause inaccurate counting results and false alarms.

- Regularly clean the inside and outside of the bill counter to prevent dust accumulation and affect the normal operation of the machine.
- Scan the QR code to get detailed instructions on how to operate the machine.



URL: <https://youtu.be/z743GGLuDic>



## I Touch Key Function Description

TELLER: Check the denomination breakdown  
CUR: Select currency  
ADD: Select accumulative counting ON/OFF  
MODE: Select counting mode: MIXED-SORT-COUNT  
BAT/BACK: Select batch number ON/OFF and return to the previous interface  
MENU/OK: Enter the setting menu/Confirm the option



## I Bill Counter Data Collection

1. Special software helps to collect false data.
2. Correctly collect the banknote data according to the released guide video to avoid incorrect use: <https://youtu.be/4ZIQXOD8Cek>



**Dear Customers,**  
**contact us for further assistance:**

Email  
wei@weirong.cn

Phone  
+86 13858700195

WhatsApp  
+86 13858700195

Website  
www.hkweirong.com



## I Flea Market :

Count mixed denominations of one currency



MIXED MODE

DEN	PCS	VALUE
100	1	100
20	1	20
10	1	10
1	18	18
<b>TOTAL</b>	<b>21</b>	<b>148</b>

Breakdown list

## I Dining car :

Count the number of one denomination



COUNT MODE

## I Ultra Compact and Lightweight :

Sort other denominations from main denomination



IMAGE ERROR



SORT MODE

